



Package Contents

- Phone Adapter with Router
- 5 V Power Adapter
- RJ-45 Ethernet Cable
- RJ-11 Phone Cable (not included with all models)
- Power Adapter
- Quick Installation

Phone Adapter with Router

VoIP
Voice

Quick Installation

Model No. SPA2102



Before You Begin

Make sure you have the following:

- An active Internet connection
- An active Internet phone service account and its settings
- A cable/DSL modem
- One computer for configuration of the Phone Adapter
- An analog telephone or fax machine with an RJ-11 phone cable

Connect the Phone Adapter

- A** Power off your network devices, including your modem and PC.
- B** Connect one end of an RJ-11 phone cable to the Phone Adapter's PHONE 1 port. Connect the other end to your analog telephone or fax machine.

IMPORTANT: Do not connect the PHONE port to a telephone wall jack. Make sure you only connect a telephone or fax machine to the PHONE port. Otherwise, the Phone Adapter or the telephone wiring in your home or office may be damaged.



B

- C** Repeat Step B with the PHONE 2 port if you have an additional telephone or fax machine to connect.

D Connect one end of an Ethernet network cable (included) to the ETHERNET port of the Phone Adapter. Connect the other end to the Ethernet port of your PC.



E Connect one end of a different Ethernet network cable to the INTERNET port of the Phone Adapter. Connect the other end to your cable/DSL modem.



F Power on the cable/DSL modem.

E

G Connect the included power adapter to the Phone Adapter's power port, and then plug the power adapter into an electrical outlet. The power LED on the front panel will light up as soon as the Phone Adapter powers on.



G

H Power on your PC.

NOTE: Make sure your PC's Ethernet adapter is set to obtain an IP address automatically. For more information, refer to Windows Help.